



Fill, Coil & Pan Section

1. Spray branches
2. Spray branch grommets
3. Spray nozzles & nozzles grommets
4. Coil
5. BACross 2 - Fill sheets with integrated drift eliminators
6. Drift eliminators
7. Combined inlet shields
8. Fan cylinder
9. Fan guard
10. Axial fan assembly (see detailed view)
11. Motor base & adjust rod
12. Upper pump piping
13. Sleeve & clamps (not visible)
14. Lower pump piping
15. Spray pump

with volute
without volute
seal kit
16. Make-up valve assembly
17. Float ball
18. Access door
19. Bleed line with manual valve (not visible)
20. Pan strainer
21. Pan strainer hood
22. Heater
23. Low level cut out switch
24. Heater thermostat
25. Top air inlet shields ((option))




Spray pump with volute



Spray pump without volute



Seal kit



Spare parts for cooling tower

Client contact information

Name _____

Company _____

Telephone _____

Email _____

Unit model _____

Serial number _____

Your BAC contact

Name _____

Telephone _____


Email _____

Axial fan assembly

- A. Axial fan
- B. Fan bushing
- C. Fan shaft
- D. Bearing with flinger collar
- E. Fan locking collar
- F. Bearing support
- G. Impervix Fan motor

H. Drive set

- Motor sheave & bushing
- Aluminium fan sheave & bushing
- Belt set



Quantities may vary according to the unit type.